FIG. 1




FIG. 2






FIG. 3









FIG. 6






FIG. 8




FIG. 9





FIG. 10

()




SPECIFY PART OF MALFUNCTION MALFUNCTION USE BASIC STATUS TO FIND ABNORMAL INPUT UNIT SPECIFY PART OF PAPER JAM PAPER JAM SPECIFY ABNORMAL INPUT UNIT SPECIFY PARTICULAR PANEL OPEN **DISPLAY MESSAGE** PAPER SIZE INCORRECT SPECIFY PAPER-END DECK SPECIFY PARTICULAR PAPER END

 (\hat{j})

REPRESENTS COMMAND STATUS.

()

FIG. 11A



()

